

## Using the Zero Clearance Plugs

Using a sharp pointed blade cut a circle above the area as shown below to expose the ball. Do not remove the outer parts of the label as in the final step, tape adheres better to the smooth label surface.



Next we extract the ball similar to the instructions for the CLI-8 plugs. Try NOT to nick or damage the sides of the hole. The plug sides must fit intimately with the sides. This is not a requirement for the CLI-8 plugs.



Fit in the plug till flush to the top as illustrated above.

Finally, cut a rectangular strip of the included Aluminum Metal Duct Tape and cover as much of the width of the plug of the cartridge as possible. Press over the tape to maximize adhesion. See below.



When removing the plug in the future use a toothpick or something pointed and grab onto the middle hole of the plug and pry out.